

## Front/Rear Turn Signal Bulb

### **▲ WARNING**

- \* The light bulb becomes very hot while the light is ON, and remain hot for a while after it is turned OFF. Be sure to let it cool down before servicing.


### **CAUTION:**

- \* Wear clean gloves while replacing the bulb.

### **NOTE:**

- \* Be sure to turn the ignition switch OFF when replacing the bulb.

1. Remove the three screws(1).
2. Remove the turn signal lens(2).



- (1) Screws
- (2) Turn signal lens