

ITEMS	FREQUENCY	WHICHEVER → COMES FIRST ↓		ODOMETER READING [NOTE (1)]								Refer to pages
		× 1,000 km	1	6	12	18	24	30	36			
		× 1,000 mi	0.6	4	8	12	16	20	24			
		NOTE	MONTH		6	12	18	24	30	36		
DRIVE CHAIN											EVERY 1,000 km (600 mi) I, L	61
DRIVE CHAIN SLIDER				I		I		I				66
BATTERY			I	I	I	I	I	I				77
BRAKE FLUID	NOTE (5)		I	I	R	I	I	R				13
BRAKE PAD WEAR			I	I	I	I	I	I				75
BRAKE SYSTEM			I		I		I		I			13, 75
* BRAKE LIGHT SWITCH					I		I		I			—
* HEADLIGHT AIM					I		I		I			—
CLUTCH SYSTEM			I	I	I	I	I	I	I			17
SIDE STAND					I		I		I			67
* SUSPENSION					I		I		I			—
* NUTS, BOLTS, FASTENERS			I		I		I		I			—
** WHEELS/TYRES					I		I		I			—
** STEERING HEAD BEARINGS			I		I		I		I			—