


OPERATING INSTRUCTIONS

INSTRUMENTS AND INDICATOR LAMPS

The instruments are mounted above the headlight case and the indicator lamps in the indicator panel built in the upper holder of handlebars.

Their functions and operating methods are described in the table in the next page.



- ① Tachometer
- ①-a Tachometer RED zone
- ② Speedometer
- ③ Odometer
- ④ Trip-meter
- ④-a Trip-meter reset knob
- ⑤ High beam indicator lamp
- ⑥ Turn signal indicator lamp
- ⑦ Oil pressure warning lamp
- ⑧ Neutral indicator lamp

