

Service Required	Months or Miles, whichever occurs first					Page Reference	
		First	Second	Third	Report Every		
	Month	—	6	12	6		12
	Mile	600	3,000	6,000	3,000		6,000
km	1,000	5,000	10,000	5,000	10,000		
*Engine Oil—change	○	Every 2,000 miles (3,000 km)				32	
*Oil Filter Element—replace	○	Every 4,000 miles (6,000 km)				32	
Engine Oil Pressure—check			○		○	34	
Oil Pump Strainer—clean	Every 24 months or 12,000 miles (20,000 km)					34	
Oil Tank and Lines—check		○	○	○		34	
*Spark Plugs—clean and adjust to replace		○	○	○		35	
*Contact Breaker Points—check or service		○	○	○		36	
Ignition Timing—check or adjust	○	○	○	○		36	
Valve Tappet Clearance—check or adjust	○	○	○	○		39	
Cam Chain—adjust	○	○	○	○		41	
*Air Cleaner—clean and replace		○			○	42	
Throttle Operation—check			○		○	—	
Carburetor—check or adjust		○	○	○		43	
*Fuel Valve Strainer—clean		○	○	○		44	
*Fuel Tank and Fuel Lines—check		○	○	○		45	
*Clutch—check or adjust	○	○	○	○		45	
*Drive Chain and Sprockets—adjust and lubricate or replace	○	○	○	○		46	
	○	○	○	○		48	

“*” denotes do-it-yourself service. Others should be serviced at dealer’s service shop. Take your motorcycle to the nearest dealer for servicing at the specified intervals.