

when charging or using in enclosed space. Always shield eyes when working near batteries.

KEEP OUT OF REACH OF CHILDREN.

a. Remove battery retainer and disconnect the ground (-) negative cable connection first and the positive (+) cable last. The battery can now be lifted from its mounting. Note the positioning of the cables, protective rubber (+) terminal cover and battery mount rubber pads as well as the routing of the battery vent tube. Before installing the battery, clean the battery and its mounting area with water. Baking soda and water can be used to remove any existing corrosion.

b. Battery installation is performed in the reverse order of removal. Pay particular attention to the battery rubber mounts pads and the vent tube routing. Install the battery vent tube as illustrated. Connect and protect the positive (+) terminal with the rubber insulator first. Connect the negative (-) terminal second.

WARNING: Check the fuel tank over flow tube for clogging, bending and cracking.

CAUTION:

1. Do not overtighten these terminal connections as damage to the battery terminals may result.
2. When installing the battery, route the battery breather tube as shown in the figure and be careful not to bend or twist the breather tube. A bent or kinked breather tube may pressurize the battery and damage its case.

NOTE: Apply petroleum jelly to the battery terminals to retard corrosion.

