## **OPERATION**

## PRE-RIDE INSPECTION

## **WWW.WARNING**

\* If the Pre-ride Inspection is not performed, serious damage or an accident may result.

Inspect your motorcycle every day before you start the engine. The items listed here will only take a few minutes, and in the long run they can save time, expense, and possibly your life.

- 1. Engine oil level—add engine oil if required (pages 24—25). Check for leaks.
- 2. Fuel level-fill fuel tank when necessary (page 23). Check for leaks.
- 3. Front and rear brakes—check operation; make sure there is no brake fluid leakage. Adjust free play if necessary (pages 18—20).

- 4. Tires—Check condition and pressure (pages 2 and 27).
- 5. Throttle-check for smooth opening and closing in all steering positions.
- Lights and horn-check that headlight, tail/stoplight, turn signals, indicators and horn function properly.
- 7. Engine stop switch—check for proper function (page 30).

Correct any discrepancy before you ride. Contact your authorized Honda dealer for assistance if you cannot correct the problem.