


## TOOL KIT

The tool kit is in the storage compartment behind the left side cover. To open the storage compartment cover (2), insert and turn the ignition key (1) counterclockwise. Some roadside repairs, minor adjustments and parts replacement can be performed with the tools contained in the kit.



(1) Ignition key

(2) Storage compartment cover

- 8 mm open end wrench
- 10 x 12 mm open end wrench
- 14 x 17 mm open end wrench
- Pliers
- No. 4 Screw driver
- No. 2 Plus minus driver
- Screwdriver grip
- 12 mm box end wrench
- 22 mm box end wrench
- 27 mm box end wrench
- 10 x 12 mm box end wrench
- Spark plug wrench
- Feeler gauge 0.7 mm
- Tool bag
- Pin spanner
- 5 mm hex. wrench
- 6 mm hex. wrench