

ITEM	FREQUENCY	WHICHEVER → COMES FIRST ↓ NOTE	ODOMETER READING [NOTE (1)]								REFER TO PAGE
			× 1,000 km	1	6	12	18	24	30	36	
			× 1,000 mi	0.6	4	8	12	16	20	24	
		MONTH	6	12	18	24	30	36			
* FUEL LINE					I		I		I	—	
* THROTTLE OPERATION					I		I		I	84	
* CHOKE OPERATION					I		I		I	—	
AIR CLEANER		NOTE (2)					C		C	86	
CRANKCASE BREATHER		NOTE (3)			C	C	C	C	C	80	
SPARK PLUG					I		R		I	81	
* VALVE CLEARANCE							I			—	
ENGINE OIL			R		R		R		R	76	
ENGINE OIL FILTER			R		R		R		R	77	
* ENGINE IDLE SPEED			I	I	I	I	I	I	I	85	
RADIATOR COOLANT		NOTE (4)			I		I		R	25	
* COOLING SYSTEM					I		I		I	—	
* SECONDARY AIR SUPPLY SYSTEM					I		I		I	—	