

The immobilizer system (HISS) indicator continues to flash every 2 seconds during 24 hours when the ignition switch is OFF. After this period, the indicator automatically switches off.


To operate this function, proceed as follows:

1. Turn the ignition switch ON.
2. Push and hold the right control button (2).

The immobilizer system (HISS) indicator (1) instantly flash, the function is enabled.

3. Turn the ignition switch OFF and the key is pulled out, then the indicator starts to flash.

Whenever the ignition switch is turned ON, the light operation is canceled.



- (1) Immobilizer system (HISS) indicator
- (2) Right control button