

ITEM	FREQUENCY	WHICHEVER → COMES FIRST ↓ NOTE	ODOMETER READING [NOTE (1)]								Refer to Page
			× 1,000 km	1	6	12	18	24	30	36	
			× 1,000 mi	0.6	4	8	12	16	20	24	
		MONTH		6	12	18	24	30	36		
DRIVE CHAIN			I, L EVERY 1,000 km (600 mi)								94
DRIVE CHAIN SLIDER					I		I		I	100	
BRAKE FLUID		NOTE (4)		I	I	R	I	I	R	26	
BRAKE PAD WEAR				I	I	I	I	I	I	108	
BRAKE SYSTEM			I		I		I		I	26, 108	
* BRAKE LIGHT SWITCH					I		I		I	—	
* HEADLIGHT AIM					I		I		I	—	
CLUTCH SYSTEM			I	I	I	I	I	I	I	29	
SIDE STAND					I		I		I	102	
* SUSPENSION					I		I		I	101	
* NUTS, BOLTS, FASTENERS			I		I		I		I	—	
** WHEELS/TYRES					I		I		I	—	
** STEERING HEAD BEARINGS			I		I		I		I	—	