
- 5. Push the right control button until the desired time is displayed.
 - The time is advanced by one minute, each time the button is pushed.



When the ignition switch is turned OFF while set the clock in the adjust mode, the time will be fixed as just before the ignition OFF.

If no operation is performed for 30 seconds during the time adjustment mode, the adjustment will be cancelled.

The clock will be reset 1:00 if the battery is disconnected.

- (1) Digital clock
- (3) Right control button