





Digital clock

Shows hour and minute. To adjust time, proceed as follows :

1. Turn the ignition switch ON.
2. Press and hold both the HOUR (1) and MINUTE (2) button for more than 2 seconds. The display will be set mode.
3. To set the hour, press and release the HOUR button (1) until the desired hour and AM/PM setting are displayed.
4. To set the minute, press and release the MINUTE button (2) until the desired minute is displayed.
The minute display will return to “00” when “60” is reached without affecting the hour display.
5. Push the RESET button (3) to enter the time.



- (1) HOUR button
- (2) MINUTE button
- (3) RESET button

