



FEATURES (Not required for operation)

STEERING LOCK


To lock the steering, turn the handlebars all the way to the left; turn the key (1) to LOCK while pushing in. Remove the key.

To unlock the steering, turn the key to OFF while pushing in.

▲WARNING

* Do not turn the key to LOCK while riding the motorcycle; loss of vehicle control will result.

To lock



To unlock

(1) Ignition key

- (A) Push in
- (B) Turn to LOCK
- (C) Turn to OFF

