



ITEM	FREQUENCY	WHICHEVER →		ODOMETER READING [NOTE (1)]								
		COMES	× 1,000 km	1	6	12	18	24	30	36	REFER TO PAGE	
		FIRST	× 1,000 mi	0.6	4	8	12	16	20	24		
NOTE	MONTH		6	12	18	24	30	36				
DRIVE CHAIN				EVERY 1,000 km (600 mi) I, L								68
BRAKE FLUID	(NOTE 4)			I	I	R	I	I	R		19	
BRAKE SHOE/PAD WEAR				I	I	I	I	I	I		81, 82	
BRAKE SYSTEM			I		I		I		I		18, 81, 82	
* BRAKE LIGHT SWITCH					I		I		I		88	
* HEADLIGHT AIM					I		I		I		41	
CLUTCH SYSTEM			I	I	I	I	I	I	I		23	
SIDE STAND					I		I		I		75	
* SUSPENSION					I		I		I		—	
* NUTS, BOLTS, FASTENERS			I		I		I		I		—	
** WHEELS/TYRES					I		I		I		—	
** STEERING HEAD BEARINGS			I		I		I		I		—	

