

Installation Notes:

Position the front wheel between the fork legs and insert the axle from the left side, through the left fork leg and wheel hub.

CAUTION:

- * **When installing the wheel, fit the left brake disc carefully between the brake pads to avoid damaging the pads.**

Tighten the axle bolt to the specified torque.

Front axle torque:

60 N·m (6.0 kg-m, 43 ft-lb)

Fit the right caliper over the disc, taking care not to damage the brake pads. Install the caliper mounting bolts, and tighten them to the specified torque.

Caliper mounting bolt torque:

27 N·m (2.7 kg-m, 20 ft-lb)