

## INSTRUMENTS AND INDICATORS

The indicators are contained in the instrument panel. Their functions are described in the tables on the following pages.

- (1) Control button A
- (2) Left turn signal indicator
- (3) Low fuel indicator
- (4) Neutral indicator
- (5) Tachometer
- (6) High beam indicator
- (7) PGM-FI malfunction indicator lamp (MIL)
- (8) Tachometer red zone
- (9) Tachometer red zone indicator
- (10) Right turn signal indicator
- (11) Warning indicator
- (12) Multi-function display
- (13) Immobilizer system (HISS) indicator
- (14) Control button B

