(Ref.No.) Description	Function
(12) Multi-function display	The display includes the following functions; This display shows the initial display (page 19).
Low oil pressure indicator/High coolant temperature indicator/HESD indicator	Lights the low oil pressure indicator and/or high coolant temperature indicator to notify that there is an abnormality in engine oil pressure and/or coolant temperature when the warning indicator lights. See page 24, 25. Also, lights the HESD indicator to notify when there is an abnormality in the HESD (Honda Electronic Steering Damper) (page 26).
Speedometer	Shows riding speed (page 28).
Digital clock	Shows hour and minute (page 36).
Coolant temperature meter	Shows coolant temperature (page 21).