

(Ref.No.) Description	Function
(14) Combined ABS indicator (amber) 〈 CBR1000RR ABS〉	This indicator normally comes on when the ignition switch is turned ON, and goes off after you ride the motorcycle at speed above 10 km/h (6 mph). If there is a problem with the Combined ABS, this indicator lights or flashes and remains on (page 100).
(15) Control button B	Use this button for the following purposes. <ul style="list-style-type: none"> • To change indication of current fuel mileage, average fuel mileage, and fuel consumption (page 36) • To change unit of speedometer, odometer, tripmeter and fuel mileage meter (E type only) (page 39) • To change indication mode of fuel mileage (page 40) • To change the reset mode of tripmeter A and fuel mileage meter (page 38) • To adjust time (page 41) • To change setting of the tachometer red zone indicator activation revolution and indication pattern (page 43)