


HEADLIGHT AIM VERTICAL ADJUSTMENT

Vertical adjustment can be made by turning the screws (1) and (2) in or out as necessary.

Obey local laws and regulations.



- (1) Screw (low beam)
- (2) Screw (high beam)

- (A) Up
- (B) Down