

5. Tyres—check condition and pressure (pages 64 – 69 ).
6. Drive chain—check condition and slack (page 120 ). Adjust and lubricate if necessary.
7. Throttle—check for smooth opening and full closing in all steering positions (page 118).
8. Lights and horn—check that headlight, brake/taillights, position light, license light, turn signals, indicators and horn function properly.
9. Engine stop switch—check for proper function (page 76 ).
10. Side stand ignition cut-off system—check for proper function (page 128 ).