

ITEM	FREQUENCY	WHICHEVER → COMES FIRST ↓ NOTE	ODOMETER READING [NOTE (1)]								Refer to Page	
			× 1,000 km	1	6	12	18	24	30	36		
			× 1,000 mi	0.6	4	8	12	16	20	24		
		NOTE	MONTH		6	12	18	24	30	36		
	DRIVE CHAIN			EVERY 1,000 km (600 mi) I, L								86
	DRIVE CHAIN SLIDER					I			I		I	92
	BRAKE FLUID	NOTE (4)			I	I	R	I	I	R		27, 28
	BRAKE PADS WEAR				I	I	I	I	I	I		100
	BRAKE SYSTEM			I		I		I		I		27, 100
*	BRAKE LIGHT SWITCH					I		I		I		108
*	HEADLIGHT AIM					I		I		I		54
	CLUTCH SYSTEM			I	I	I	I	I	I	I		29
	SIDE STAND					I		I		I		94
*	SUSPENSION					I		I		I		93
*	NUTS, BOLTS, FASTENERS			I		I		I		I		—
**	WHEELS/TYRES					I		I		I		—
**	STEERING HEAD BEARINGS			I		I		I		I		—