



# Troubleshooting

**Engine Will Not Start (HISS indicator stays on).....** P. 82

**Overheating (High coolant temperature indicator is on).....** P. 83

**Warning Indicators On or Flashing .....** P. 84

Low Oil Pressure Indicator ..... P. 84

PGM-FI (Programmed Fuel Injection)

Malfunction Indicator Lamp (MIL)..... P. 84

ABS (Anti-lock Brake System) Indicator

(CBR500RA only)..... P. 85

**Other Warning Indication .....** P. 86

Fuel Gauge Failure Indication ..... P. 86

**Tyre Puncture .....** P. 87

**Electrical Trouble.....** P. 94

Battery Goes Dead ..... P. 94

Burned-out Light Bulb ..... P. 94

Blown Fuse..... P. 99

