

Tripmeter

Shows mileage per trip.

There are two tripmeters, tripmeter A (4) and tripmeter B (5). Switch between the A and B displays by pressing the ADJ button (6) repeatedly.



To reset the tripmeter, push and hold the RESET button (7) with the display in the tripmeter A or tripmeter B mode.

Speed and Mileage Unit Change (E type only)

The speedometer displays both “km/h” and “mph”.

The odometer/tripmeter displays both “km” and “mile”.

Push the RESET button (7) to select “km/h”/“km” or “mph”/“mile” with the display in the tripmeter A mode.



- (4) Tripmeter A
- (5) Tripmeter B

- (6) ADJ button
- (7) RESET button