



Digital Clock

Shows hour and minute. To adjust the time, proceed as follows:

1. Turn the ignition switch ON.
2. Push and hold both the ADJ button (2) and RESET button (3) for more than 2 seconds. The clock will be set in the adjust mode with the hour display flashing.



3. To set the hour, push the RESET button until the desired hour is displayed.



- (1) Digital clock
- (2) ADJ button
- (3) RESET button