

5. Tyres—check condition and pressure (pages 47 – 49 ).
6. Drive chain—check condition and slack (page 108 – 109 ). Adjust and lubricate if necessary.
7. Throttle—check for smooth opening and full closing in all steering positions (page 105).
8. Lights and horn—check that headlight, stop/tail light, turn signals, indicators and horn function properly.
9. Engine stop switch—check for proper function (page 59 ).
10. Side stand ignition cut-off system—check for proper function (page 116 ).