


## Instruments *(Continued)*

### Display Setting

Following items to change sequentially.

- Time format setting
- Clock setting
- Backlight brightness adjustment
- Activating/deactivating of tripmeter A, average fuel mileage and fuel consumption automatic reset mode
- Setting of HISS indicator
- Changing of speed and mileage unit
- Changing of fuel mileage meter unit



➡ Press and hold **SEL** button and **SET** button

⇨ Press **SET** button