

Instruments *(Continued)*

- 3 Press **SEL** button until the desired minute is displayed.
▶ Press and hold to advance the minute fast.



- 4 Press **SET** button. The clock is set, and then the display moves to the backlight brightness adjustment.

3 Backlight brightness adjustment:

You can adjust the brightness to one of three levels.

- 1 Press **SEL** button. The brightness is switched.
- 2 Press **SET** button. The backlight is set, and then the display moves to activating/deactivating of tripmeter A, average fuel mileage and fuel consumption automatic reset mode.

