

MAINTENANCE SCHEDULE

The following Maintenance Schedule specifies all maintenance required to keep your motorcycle in peak operating condition. Maintenance work should be performed in accordance with standards and specifications of Honda by properly trained and equipped technicians. Your Honda dealer meets all of these requirements.

Perform the Pre-ride Inspection (page 62) at each scheduled maintenance period.

I: INSPECT AND CLEAN, ADJUST, LUBRICATE OR REPLACE IF NECESSARY

C: CLEAN R: REPLACE A: ADJUST L: LUBRICATE

ITEMS	FREQUENCY	WHICHEVER → COMES FIRST ↓ NOTE	ODOMETER READING [NOTE (1)]								Refer to pages
			×1,000 km	1	6	12	18	24	30	36	
			×1,000 mi	0.6	4	8	12	16	20	24	
		NOTE	MONTHS	6	12	18	24	30	36		
* FUEL LINE					I		I		I	—	
* THROTTLE OPERATION					I		I		I	86	
* AIR CLEANER		NOTE (2)				R			R	—	
SPARK PLUGS				EVERY 12,000km (8,000mi) I, EVERY 24,000km (16,000mi) R						82	
* VALVE CLEARANCE							I			—	
ENGINE OIL			R		R		R		R	78	
ENGINE OIL FILTER			R		R		R		R	79	
* ENGINE IDLE SPEED			I	I	I	I	I	I	I	87	
RADIATOR COOLANT		NOTE (3)			I		I		R	36	
* COOLING SYSTEM					I		I		I	—	
* SECONDARY AIR SUPPLY SYSTEM					I		I		I	—	