

ITEMS	FREQUENCY	WHICHEVER → COMES FIRST ↓ NOTE	ODOMETER READING [NOTE (1)]								Refer to pages
			×1,000 km	1	6	12	18	24	30	36	
			×1,000 mi	0.6	4	8	12	16	20	24	
			MONTH		6	12	18	24	30	36	
DRIVE CHAIN			EVERY 1,000 km (600 mi) I, L								88
DRIVE CHAIN SLIDER					I			I		I	94
BRAKE FLUID		NOTE (3)		I	I	R	I	I	R		30
BRAKE PAD WEAR				I	I	I	I	I	I		102
BRAKE SYSTEM			I		I		I		I		30, 102
* BRAKE LIGHT SWITCH					I		I		I		—
* HEADLIGHT AIM					I		I		I		—
CLUTCH SYSTEM			I	I	I	I	I	I	I		34
** EXHAUST VALVE CONTROL CABLE							I				—
SIDE STAND					I		I		I		96
* SUSPENSION					I		I		I		95
* NUTS, BOLTS, FASTENERS			I		I		I		I		—
** WHEELS/ TYRES					I		I		I		—
** STEERING HEAD BEARINGS			I		I		I		I		—