

Tires - Check the air pressure and the tires for wear or damage.

Battery electrolyte - Check the level and add if necessary.

Throttle operation - Check throttle operation, cable routing and free play.

Correct or replace if necessary.

Lighting - See if all lights operate properly.

Drive chain - Check condition of drive chain and measure the chain tension. Adjust if the chain tension is incorrect. Lubricate if it appears dry. Replace if it is badly worn or damaged.

---

Llantas - Revise la presión del aire, estado de desgaste o daño de las llantas.

Electrólito de la batería - Revise el nivel y agregue, si es necesario.

Funcionamiento del acelerador - Revise el estado de funcionamiento del acelerador, instalación de sus cables, y sus juegos libres. Corrija o reemplace, si es necesario.

Iluminación - Revise si todas las lámparas funcionen normalmente.

Cadena de transmisión - Mida el juego; la dureza de operación debido a lubricación inadecuada y otras condiciones esenciales para suave funcionamiento.