

manuals.....	186
warranty.....	190
spark knock.....	87
spark plug.....	111
specifications.....	169
speedometer.....	19
start button.....	22
starting,	
engine.....	45
troubleshooting.....	147
steering lock.....	61
stop switch, engine.....	22
stopping engine.....	50
storage,	
owner's manual.....	84
scooter.....	138
switch,	
engine stop.....	22
headlight dimmer.....	23
ignition.....	20

turn signal.....	23
------------------	----

T

temperature indicator, coolant.....	19
theft prevention tips.....	63
throttle.....	107
tires,	
air pressure.....	118
flat.....	152
replacing.....	122
training, rider.....	3, 32
transporting your scooter.....	142
trouble, unexpected.....	145
troubleshooting, starting.....	147
turn signal indicator.....	19