

# Parking

1. Look for a level parking area. If you can't park on a paved surface, make sure the ground surface is firm, especially under the center stand. Make sure flammable materials such as dry grass or leaves do not come in contact with the exhaust system when parking your scooter. Refer to *Catalytic Converter*, page 183.  
If you must park on a hill, position the rear tire against the curb at a 45 degree angle.
2. Use the center stand and center stand lock (page 27) to support the scooter while parked.
  - To lower the center stand, stand on the left side of the scooter. Hold the left handle grip and rear grip. Press down on the tip of the stand with

your right foot and, simultaneously, pull up and back.

- If you have to park on a soft surface, insert something solid under the stand for support.

