


### Tread Wear

You must periodically confirm the tread wear depth.

Replace tyres before tread depth (1) at the centre of the tyre reaches the following limit:

Minimum tread depth	
Front:	3.0 mm (0.12 in)
Rear:	3.0 mm (0.12 in)



(1) Tread depth

### Tube Repair and Replacement

If a tube is punctured or damaged, you should replace it as soon as possible. A tube that is repaired may not have the same reliability as a new one, and it may fail while you are riding.

If you need to make a temporary repair by patching a tube or using an aerosol sealant, ride cautiously at reduced speed and have the tube replaced before you ride again.

Any time a tube is replaced, the tyre should be carefully inspected as described on page 34.