

Fuel Supply

The CRM250AR uses only unleaded petrol. Always stop the engine before refueling and keep well clear of naked flames, sparks or heat sources.



Caution

Petrol is highly flammable. Improper handling will result in severe injury.

When handling the petrol:

- Always stop the engine and keep away from flames, sparks or heat sources.
- Refuel outside.
- Wipe off spilled petrol straight away.

Refueling

1. Lift up the key cover. Insert the ignition key and turn to the right to open the fuel fill cap.

