

Basic Maintenance

Basic Maintenance

This section describes basic maintenance procedures that should be performed on a regular basis.

Do not carry out any work beyond your knowledge and skill, and always use proper tools.

Contact an Authorized Honda Dealer if you do not have proper tools or skills required for a particular job.