

Battery Care


If the motorcycle is operated with insufficient battery electrolyte, sulfation and battery plate damage will occur.

If rapid loss of electrolyte is experienced, or if your battery seems to be weak, causing slow starting or other electrical problems, see your authorized Honda dealer.

Battery electrolyte:

The battery (1) is behind the left side cover.

Remove the side cover. Check the electrolyte.



(CT 185)

Mantenimiento de la batería

Se se opera la motocicleta con insuficiente electrólito en la batería, ocurrirá sulfatación y daños en la placa de la batería.

Si se nota una pérdida rápida de electrólito, o se parece que la batería se debilita, causando unos arranques lentos u otros problemas eléctricos, llévala a su distribuidor autorizado Honda.

Electrólito de la batería:

La batería (1) está detrás de la cubierta lateral izquierda. Quitar la cubierta lateral. Comprobar el electrólito.

