

## ● GEAR CHANGE PEDAL


The gear change pedal ① located near the left foot rest is of the progressive shift, positive stop type, which means one full stroke of the gear change pedal will shift only one gear position. The shifting sequence is arranged as shown in the figure.

Shifting to low from neutral is performed by depressing the gear change pedal; successive shifting into second and top are made by depressing the pedal in sequence.

Shifting down in gear is accomplished by lifting up the gear change pedal in successive sequence.



① Gear change pedal



Gear change sequence