


i-Multi-Information Display



Audio play time

Bluetooth® device status icon: The connection status of *Bluetooth*® devices is displayed.

USB device status icon: Displayed when a USB device is connected.

Playing status icon: The playing status of audio system is displayed.

Audio device status icon, Sound device status icon: The current audio mode is displayed. The status icons blink while a track is stopped. ➡P.50

Artist name, Track title: While playing a track, displayed when the **VOLUME**, **TRACK** or **MODE** button is operated, or when the audio information display is chosen. ➡P.22

▶ Music information may not be displayed. If the character code in use is not supported, "." will be displayed.

Audio play time: Displayed when the **VOLUME**, **TRACK** or **MODE** button is operated while playing a track.

Volume level: Displayed when the **VOLUME** or **MODE** button is operated, or when the **TRACK** button is operated while playing a track.