


## Audio System *(Continued)*

### To reset registered *Bluetooth*® devices

- 1 Select the audio mode 1 or 3 using the **MODE** button.  **P.50**
  - ▶ The beep signal cannot be heard when the mode 2 or 4 is chosen.
- 2 Press and hold the **MODE** buttons for 10 seconds. The long beep (1 second) will sound and the registered informations will be deleted.
  - ▶ If the registered informations cannot be deleted, the short beep sounds three times.
- 3 Delete the *Bluetooth*® information of “Honda Motorcycle Audio” from the audio device according to its manual.