

Symptom	Cause/remedy
<p>Sounds skip Noises mix</p>	<p>Presence of another <i>Bluetooth</i>® device or a device that emits electromagnetic waves such as communication equipment in the vicinity sometimes affects the communication.</p>
	<p>Due to the characteristics of <i>Bluetooth</i>®, though in rare cases, the system operation may become unstable. When it remains unstable, turn off the power to the audio system or the device being used, and then turn it on again.</p>
	<p>The storage location of the <i>Bluetooth</i>® device sometimes affects the audio system and communication. When sounds skip or noises mix, change the location of the device. For example, when the device is kept in a pocket of clothing sandwiched in between the rider and passenger, the communication may be affected. (The <i>Bluetooth</i>® receiver is located near the front of the left saddle bag.) Also, weather, buildings in vicinity, road conditions, etc. can sometimes affect the communication.</p>