

CLEANING

Clean your motorcycle regularly to protect the surface finishes and inspect for damage, wear, and oil or hydraulic fluid seepage.

CAUTION

- * *Avoid spraying high pressure water (typical in coin-operated car washes) at the following areas:*

Radiator

Brake Master Cylinder

Wheel Hubs

Muffler Outlets

Under Fuel Tank

Under Seat

Ignition Switch

Steering Lock

Handlebar switches

1. After cleaning, rinse the motorcycle thoroughly with plenty of clean water. Strong detergent residue can corrode alloy parts.

2. Dry the motorcycle, start the engine, and let it run for several minutes.

WARNING

- * *Braking performance may be impaired immediately after washing the motorcycle.*
3. Test the brakes before riding the motorcycle in traffic. Several applications may be necessary to restore normal braking performance.

STORAGE

Storage for more than a month, or winter storage requires preventive maintenance to prevent deterioration of the fuel, tires, battery; and corrosion.

See your authorized Honda dealer for this service.