

ITEM	FREQUENCY	WHICHEVER → COMES FIRST ↓ NOTE	ODOMETER READING [NOTE (1)]								REFER TO PAGE
			× 1,000 km	1	6	12	18	24	30	36	
			× 1,000 mi	0.6	4	8	12	16	20	24	
					6	12	18	24	30	36	
* FUEL LINE						I		I		I	—
* THROTTLE OPERATION						I		I		I	107
AIR CLEANER		NOTE (2)					R			R	93
CRANKCASE BREATHER		NOTE (3)			C	C	C	C	C	C	96
SPARK PLUGS						R		R		R	104
* VALVE CLEARANCE								I			—
ENGINE OIL				R		R		R		R	97
ENGINE OIL FILTER				R		R		R		R	100
* ENGINE OIL STRAINER SCREEN						C		C		C	100
* ENGINE IDLE SPEED				I	I	I	I	I	I	I	108
RADIATOR COOLANT		NOTE (5)				I		I		R	33
* COOLING SYSTEM						I		I		I	—
* SECONDARY AIR SUPPLY SYSTEM						I		I		I	—