

- Keep clear of the moving parts.

Spark plug maintenance

The ODYSSEY uses a BR9ES (NGK) or W27ESR (ND) spark plug.

1. Ensure that the area around the spark plug is clear of snow, ice, mud, etc. Disconnect the spark plug cap ① and remove the spark plug with the wrench ② provided in the tool kit.
2. Check the plug condition. The normal color is light brown. If the insulator is black or light gray check for the following

- Rester à distance des pièces mobiles.

Entretien de la bougie

L'ODYSSEY utilise une bougie BR9ES (NGK) ou W27ESR (ND).

1. S'assurer que la bougie ne soit pas entourée de neige, glace, boue, etc. Débrancher le capuchon de la bougie ① et enlever la bougie à l'aide de la clé ② fournie dans la trousse à outils.
2. Vérifier l'état de la bougie, la couleur normale étant brun pâle. Si l'isolant est noir ou gris pâle vérifier les points suivants:

