

Use the following table to help determine the cause of problems with your ODYSSEY. Contact your Honda dealer for assistance in matters beyond the scope of the table.

1. Engine will not start.

| Item | Cause | Remedy |
|----------------------|--|------------------|
| Fuel system | 1. Insufficient fuel | Add |
| | 2. Clogged fuel valve or fuel strainer | Clean |
| | 3. Clogged tank cap breather | Clean |
| | 4. Clogged fuel line | Clean |
| | 5. Clogged fuel filter | Replace |
| Electrical system | 1. Damaged, wet or fouled plug | Replace or clean |
| | 2. Incorrect plug gap | Adjust |
| Compression | 1. Loose spark plug | Retighten |
| | 2. Loose cylinder head | Retighten |
| | 3. Worn piston rings | Replace |

2. Engine does not develop sufficient power or overheats.

| Cause | Remedy |
|---|-------------|
| 1. Clogged air cleaner element | Clean |
| 2. Carbon deposits in muffler, cylinder head or on piston crown | Decarbonize |
| 3. Clogged cylinder fins | Clean |
| 4. Clogged fuel filter | Replace |