

Instruments and Indicator Lights

The indicators and warning lights are incorporated in the instruments. Their functions are described in the table on the following pages.

- | | |
|---|---|
| (1) Neutral indicator | (13) Oil pressure warning light |
| (2) High beam indicator | (14) Digital tripmeter |
| (3) Left turn signal indicator | (15) Odometer |
| (4) Radio indicator/clock | (16) Suspension select button |
| (5) Fuel gauge | (17) Suspension air pressure increase button |
| (6) Coolant temperature/suspension air pressure gauge | (18) Suspension air pressure decrease button |
| (7) Speedometer | (19) Tripmeter preset button |
| (8) Gear position indicator | (20) Tripmeter reset button |
| (9) Tachometer display | (21) Trip mode select button |
| (10) Tachometer digital readout | (22) Tachometer display button |
| (11) Voltmeter | (23) Speedometer (km/h ↔ MPH) select button
«E type» |
| (12) Right turn signal indicator | (24) Maintenance indicator |