

0–8,000 mi (0–12,000 km): Not yet time to service.

8,000–9,000 mi (12,000–14,000 km): Time to service Aspencade.

Past 9,000 mi (Past 14,000 km): The Maintenance Schedule has been exceeded.

After maintenance has been performed, be sure to reset the indicator by inserting the ignition key (2) into the slot below the maintenance indicator. The indicator's color will change to green and repeat its cycle.

---

De 0–12.000 km no ha llegado el tiempo para el mantenimiento.

De 12.000–14.000 ha llegado el tiempo para el mantenimiento en Aspencade.

Pasados los 14.000 km el período de mantenimiento se ha sobrepasado.

Una vez que se ha efectuado el mantenimiento, asegúrese de ajustar el indicador introduciendo la llave de encendido (2) en la ranura debajo del indicador de mantenimiento. El color del mantenimiento cambiará a verde y repetirá su ciclo.