

Digital Tripmeter

The tripmeter l.c. display (1) lights when the ignition switch is turned ON.




The tripmeter may be preset to any milage and shows accumulated mileage or decreasing mileage to destination.


Tripmeter l.c. display (1):

This displays accumulated or decreasing mileage.

Trip mode l.c. display (2):

This display which counting mode the tripmeter is in.

L.C. display	Trip mode	Tripmeter function
	Mode A	Count up
	Mode B	Count down,
	Mode B	then counts up



Cuentakilómetros para cada viaje digital




El indicador l.c. de cuentakilómetros para cada viaje (1) luce cuando la llave de encendido o esté en ON. El cuentakilómetros para cada viaje se puede ajustar previamente en cualquier número de millas y muestra el número de millas acumuladas o el resto hasta el punto de destino.

Indicador l.c. de cuentakilómetros para cada viaje (1):

Indica las millas acumuladas o las restantes.

Indicador l.c. de tipo de viaje (2):

Indica que tipo de cuentakilómetros funcionará.

L.C. indicator	Tipo de viaje	Función del cuentakilómetros para cada viaje
	Tipo A	Sumar
	Tipo B	Restar
	Tipo B	Luego sumar