

Headlight Dimmer Switch


Turn headlight dimmer switch (1) to “ \equiv D” for low beam, and “ \equiv D” for high beam.

Horn

When this switch (2) is pressed the horn sounds.

Passing Light Control Switch

When this switch (1) is pressed at “ \equiv D” position, the headlight flashes on to signal approaching cars or when passing.



Interruptor conmutador del haz del faro

Coloque el interruptor conmutador del haz del faro (1) en posición “ \equiv D” para obtener el haz bajo, y en posición “ \equiv D” para el alto.

Bocina

Al oprimir este interruptor (2), sonará la bocina.

Interruptor de mando de la luz de paso

Al primir este interruptor (1) en “ \equiv D” posición, el faro ilumina para dar indicaciones a vehículos o para pasar.