

MAINTENANCE

Serial Numbers

The frame and engine serial numbers are required when registering your motorcycle.


They may also be required by your dealer when ordering replacement parts. Record the numbers here for your reference.

The frame number (1) is stamped on the right side of the steering head.

The engine number (2) is stamped on top right side of the crankcase.

FRAME NO. _____

ENGINE NO. _____



MANTENIMIENTO

Números de serie

Los números de serie del motor y del bastidor son indispensables para registrar su motocicleta. También es posible que sean requeridos por su concesionario cuando éste pida piezas de repuesto. Anote los números a continuación para utilizarlos como referencia.

El número del bastidor (1) está estampado en el lado derecho del cabezal de la dirección.

El número del motor (2) está estampado en el lado superior derecho del cárter.

No. DEL BASTIDOR _____

No. DEL MOTOR _____

