

OPERATION

| Page | | Page | |
|------|---|------|------------------------------|
| 1 | MOTORCYCLE SAFETY | 41 | Helmet Holders |
| 4 | Safe Riding Rules | 42 | Travel Trunk And Saddlebags |
| 5 | Protective Apparel | | |
| 5 | Modifications | 46 | Fairing Pockets |
| 6 | Loading and Accessories | 47 | Trunk Side Pockets |
| | | 47 | Windshield Height Adjustment |
| 9 | PARTS LOCATION | 48 | Headlight Beam Adjustment |
| 12 | Instruments and Indicators | 48 | Ventilation Louvers |
| | | 49 | Seat |
| 18 | MAJOR COMPONENTS (Information you need to operate this motorcycle) | 49 | ACC Terminal |
| 18 | Rear Suspension | 50 | Protection Against Water |
| 21 | Brakes | 50 | Radio/Cassette Cover |
| 23 | Clutch | 52 | AM/FM Radio |
| 24 | Coolant | 54 | Cassette Deck |
| 26 | Fuel | 60 | Radio Antenna |
| 29 | Engine Oil | | |
| 30 | Final Drive Oil | 61 | OPERATION |
| 31 | Tubeless Tyres | 61 | Pre-ride Inspection |
| | | 62 | Starting the Engine |
| 34 | ESSENTIAL INDIVIDUAL COMPONENTS | 65 | Running-in |
| 34 | Ignition Switch | 66 | Riding |
| 35 | Right Handlebar Controls | 67 | Reverse Riding |
| 39 | Left Handlebar Controls | 69 | Braking |
| | | 70 | Parking |
| 41 | FEATURES (Not required for operation) | 70 | Anti-theft Tips |
| 41 | Steering Lock | | |